


MOUNTING INSTRUCTIONS FOR STANDARD BOARDS



The photo below shows the components of the assembly kit for mounting a board to a wall.



Please be very careful in handling the board, as they are usually printed from behind and scratch easily. Be careful not to over tighten the screws as you might crack the acrylic. In addition, check the sliders after mounting to be sure they are operational. There are two reasons they might not move freely. When it is only one or two sliders, loosen the small screw on the back of the board to adjust the resistance.



When all of the sliders don't move easily, the board is too tight to the wall. You can fix this by either loosening the mounting screws or inserting an additional washer (not included in the mounting hardware kit) between the board and the wall anchor.

Call us at 585-586-0152 (office) or 585-789-7574 (cell) with questions or concerns.